



Patch Management, Inc.

451 Tyburn Road, Fairless Hills, PA 19030 USA

215-949-9400

Spray Patching



4 Step Spray Patching Process

“One Man, One Truck!”

1. Clean out/blow out the pothole with low-pressure, high-volume air.
2. Spray coat the hole with emulsion.
3. Spray a mix of aggregate (stone) and emulsion to fill the hole.
4. Top coat with dry stone to prevent tracking.



Patch Management Inc.— Product and equipment sales, service and repairs, leasing and contract services—offering the most advanced and cost effective roadway and facility pavement preservation and management services available!

